

PREASSEMBLED SAMPLE COOLER PANELS

- > Protects operators and measuring devices
- > Improves Sampling Accuracy
- > Saves \$\$\$ on Installation Costs



Single Unit "Grab" Sample Station



- Pg 1 Part Number Format
- Pg 2 Overview & Features
- Pg 3 General Info & Startup Notes
- **Pg 4-5 Water Based Sample Station Designs**
- Pg 6 Steam Based Sample Station Design
- Pg 7 Free Standing Water/Steam Sample Station Design

MADDEN ENGINEERED PRODUCTS

Sample Cooler Station - Part Number Format

Madden sample cooler station part number tree. Contact factory for assistance defining the complete sample cooler panel required. Madden keeps material in stock to build wall mount panels in 1-2 weeks. Free standing sample cooler panels are built to order. Further customization can be provided, contact the factory with your specifications if needed.

PANEL MATERIAL

"SCSC" - CS Back Panel

'SCSS" - SS Back Panel

"SCSA" - Aluminum Panel

TYPE OF STATION

'20_" - 0 = Wall Mount

"21_" - 1 = Free Standing

- See below for "_"

OF COOLERS

Fill in "__" - with number of individual coolers to be used in this system (regardless of different models being used).

(1) S.C. per sampling source is recommended.

SAMPLE COOLER MODELS

TYPE 1

"0001" - 1.3 Sq. Ft., Copper

"0003" - 1.3 Sq. Ft., 316SS

"0003A" - 1.3 Sq. Ft., 316SS

TYPE 2

"101" - 1.3 Sq. Ft., Copper

"102" - 1.3 Sq. Ft., 316SS

"102A" - 1.3 Sq. Ft., 316SS

"105" - 1.9 Sq. Ft., 316SS

"105A" - 1.9 Sq. Ft., 316SS

"SC106" - 3.8 Sq. Ft., 316SS

"S106A" - 3.8 Sq. Ft., 316SS

- Fill in each model to be installed once, regardless of total used.
 Separate different models with another dash.
- See Sample Cooler Data Sheet for more details on individual Sample coolers.

ANCILLARY EQ.

- 1 Metering Valve
- 2 Pressure Gauge
- 3 Temperature Gauge
- 4 Relief Valve
- 5 C.W. Flow Indicator
- 6 Equipment Labels
- 7 Wall Mount Cabinet
- 8 SS Countertop
- 9 Thermal Shut Off Valve

"CUSTOMIZATION"

- C For our new (2024) compact, single cooler station with small food pan sink.
- Z Used as a "catch all" for anything that deviates outside of a standard B.O.M.

- NOTE 1: CS Panels have red oxide primer and gray acrylic enamel top coat. SS and Aluminum are sand blasted.
- **NOTE 2:** Free standing structures are made of 10# structural C channel steel, painted.
- NOTE 3: Piping used between sample coolers will match sample cooler model tubing.
- NOTE 4: Isolating ball valves are provided as needed.

Full P/N Example:

SCSC213 - 00003-106 - 1234

Madden Sampling Stations OVERVIEW

Madden sample panels, or sample stations, are pre-piped mechanical assemblies designed to provide the boiler room operator with the basic components required to safely take an accurate water or steam-based grab sample. These turnkey systems reduce time and costs required to install a grab sampling station otherwise. Reducing the temperature of your boiler water or steam samples ensures no flashing will occur which increases the accuracy of your water quality measurements. It also increase the service life of hand held water quality meters. Preassembled

Madden offers the following (3) "standardized" models:

- **1. Model No. SCSC201-0003-1234** single cooler station designed for water based grab samples.
- 2. Model No. SCSC201-106-1234 single cooler station designed for steam based grab samples.
- **3. Model No. SCSC213-0003-106-TBD** (2) sample coolers for water, (1) for steam, and a countertop for setting down your measuring instrumentation and data recording devices. *In lieu of the countertop, Madden can build this free mount sampling station with up to (5) sample coolers on the back panel.*

CONTACT THE FACTORY FOR CUSTOM FREE MOUNT STATION BUILDS.

General Sample Station FEATURES

SAMPLE COOLERS COME IN A VARIETY OF MATERIALS AND SIZES

- See our "SC DataSheet V4.2.pdf" for our full line of sample coolers.
- SS and Copper coils, Steel and SS shells.
- Mix and match to find your balance of durability and cost effectiveness.

COUNTERFLOW COOLING

- Both our Type 1 and Type 2 style sample coolers utilize counterflow for efficient cooling.
- Minimal pressure drop, vibration, and scaling equates to long service life.
- Added Teflon linear ensures coil will not rub and deteriorate against shell during thermal expansion.

UNITS CAN BE EASILY DISASSEMBLED

Madden sample coolers can be completely disassembled for maintenance if required to ensure you
get the longest service life from our products as is achievable.

TURNKEY DESIGN, SIMPLE YET EFFECTIVE

- Madden sample cooler stations focus on providing a turnkey solution without adding unnecessary features to the design.
- Our standard design includes gauges to confirm pressure drop and temperature before grabbing the sample.
- We use Swagelok compression fittings and valves where possible to keep the station compact, rugged, and leak free.
- Intended to be the best "happy medium" on the market. Not the bare minimum equipment offered, but also not more high tech and expensive than it needs to be.

FAST LEAD TIMES

• Madden keeps completed SC0003 and SC106 sample coolers in stock and has the panels, sinks, valves, and tubing in inventory so the above "1" and "2" standard sampling stations can be shipped within a week.

GENERAL INFORMATION

(Important! Read before 1st use)

WARNING! - The most important step to remember when grabbing a boiler water sample or a steam sample, is to <u>ENSURE COLD</u> <u>WATER FLOW BEFORE OPENING THE SAMPLE LINE</u>. When boiler water samples are taken without being properly cooled and the pressure is not reduced, the sample can flash to steam causing an inaccurate measurement of the boiler water quality as well as risk the safety of the operator.

GENERAL INFORMATION - These systems are a low pressure drop system used for monitoring boiler water and steam quality without shutting down the boiler system to do so. They are designed to be compact and provide minimal disturbance to your boiler room system pressure. Tubing within the sample coolers are maintenance free.

The essential elements of true representative sampling per your current boiler water/steam conditions are precise temperature, pressure, and flow control. Madden sampling stations offer a cost effective and reliable solution to meet these essential elements. The simple design is easily understood allowing for boiler room operators to use and maintain the system without the aid of outside water quality experts.

START UP - When grabbing a water or steam sample follow these basic steps:

- 1. Open cold water valve and ensure consistent flow.
- 2. SLOWLY open the sample valve and adjust its metering valve accordingly.
- 3. Double check gauges to confirm optimal sampling temperature.
- 4. Purge the sample line before grabbing a sample: As a rule of thumb, allow approximately three full "line volume lengths" to pass through the sampling station before grabbing your sample.
- 5. Close off valves in reverse order.


BOILER WATER OR STEAM? - For grab samples we recommend using one of our sample coolers with 1.3 or 1.9 sq. ft. of heat

exchanging surface area. For steam sample grabs, use a unit with at least 2.6 sq. ft. Contact the factory for further assistance with sample cooler selection.

STANDARD SAMPLE COOLER STATION OFFERINGS - Madden currently offers (3) standard sampling station designs:

- Model SCS201-0003 this system is highlighted within this data sheet. It offers a 1.3 sq. ft. 316SS sample coil rated to 3,000 PSI with a steel shell rated to 300 PSI. It is the best balance between cost effectiveness and durability for a typical boiler room WATER grab sample.
- 2. Model SCS201-106 this system offers a 3.8 sq. ft. 316SS sample coil rated to 2,500 PSI with a steel shell rated to 150 PSI. It is the best balance between cost effectiveness and durability for a typical boiler room <u>STEAM</u> grab sample.
- 3. Model SCS213-102-106-TBD this station offers multiple water sample coolers and one steam sample cooler. It also includes a counter to set down measuring instruments and data recording devices. In lieu of the counter top, you can add additional sample coolers for more blowdown processes to measured. CONTACT THE FACTORY FOR CUSTOM **FREE** MOUNT STATION BUILDS.

Model SCSC201-0003-1234: Water Based Sample Testing



N1. STAINLESS STEEL SINK W/ DRAIN

N2. SC0003 SAMPLE COOLER: 1.3 SF HEAT EXCHANGE,

316 SS COIL, 1/4" OD N3. (2) SHUT OFF BALL VALVES - SPECIFY PREFERRED TÉRMINAL CONNECTION TYPE (IE. FNPT, MNPT, COMP.)

N4. SWAGELOK HIGH FLOW METERING VALVE, 1/4" COMP. CV .03 @ 300 PSI.

N5. GLOBE VALVE, SS, 1/4" NPT

N6. WALL MOUNT/BRACKET: 20" X 24", 11 GA. CS, ACRYLIC GREY PAINT FINISH

N7. PIPING: 1/4" TUBE, 316 STAINLESS STEEL

N8. PRESSURE GAUGE, SS: 2-1/2" DIAL, 1/4" NPT STANDARD SCALE: 0-300 PSI OPTIONAL SCALES AVAILABLE UP TO 3,000 PSI

N9. TEMPERATURE GAUGE, SS: 3" DIAL, 1/2" NPT SCALE: 0-240 DEG. F.

(1) PRESSURE & (1) TEMPERATURE

N10. DRAIN: 1-1/2"

N11. NAMEPLATES/LABELS

N12. FLEXIBLE TUBE

N13. INSULATION SLEEVE

N14. IN250 PRESSURE RELIEF VALVE, SET @ 150 PSI (PIPE TO OPEN FLOOR DRAIN OR BD SEPARATOR)

COOLING WATER SIDE PRESSURE: 300 PSI DWP SAMPLE SIDE PRESSURE: 3,000 PSI DWP

TEMPERATURE LIMITS


SAMPLE SIDE/LINE: UP TO 1,000 DEG F.

VALVES ON SAMPLE SIDE AFTER COOLER: 400 DEG F.


COOLING WATER SIDE: 212 DEG F.

PANEL WEIGHT: 55 LBS

SAMPLE SIDE INLET




Model SCSC201-0003-12349-C: Compact and Cost Effective Water Based Sample Testing



BILL OF MATERIALS			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	SC102	SAMPLE COOLER (WATER/SATURATED STEAM DRUM B.D.): 1.3 SF HEAT EXCHANGE CAPACITY, 316SS COIL, 3/8" OD, SS SHELL AND TOP/BOTTOM PLATES, 1/4" CONNECTIONS. COIL SIDE RATED TO 3,850 PSI. @ 1,000 DEG F, SHELL SIDE RATED TO 300 PSI.
2	1	#	SINK: 6-7/8" X 6-3/8" X 2-1/2" (L X W X D), 22 GA, SS, 1-1/4" DRAIN
3	1	#	SAMPLE INLET BALL VALVE: SWAGELOK COMPRESSION FITTING, SS, 1/4" COMPRESSION CONNECTION
4	1	#	COLD WATER INLET BALL VALVE: SWAGELOK COMPRESSION FITTING, SS, 1/4" COMPRESSION CONNECTION
5	1	#	GLOBE VALVE: 1/4" FNPT x FNPT, SS
6	1	#	WALL MOUNT PANEL: 11 GA. CARBON STEEL, 22" LONG X 10" WIDE. EDGES TO BE BENT TO PROVIDE 1" DEPTH AND 1" TRIM FOR BOLTING TO WALL (4) 3/8" BOLT HOLES. FINISHED WITH ACRYLIC GRAY INDUSTRIAL PAINT.
7	1	#	PIPING: 1/4" OD X 0.035" TUBE, 316SS
8	1	#	PRESSURE GAUGE: 1/4" MNPT, SS, 2-1/2" DIAL, 0-150 PSI (OPTIONS UP TO 3,000 PSI)
9	1	#	TEMPERATURE GAUGE: 1/2" MNPT, SS, 3" DIAL, 0-240 DEG F.
10	1	IN250	PRESSURE RELIEF VALVE: SWAGELOK POPPET CHECK VALVE, 1/4" MNPT, 316SS, 150 PSI CRACKING PRESSURE
11	1	IN201	FLOW METERING VALVE: SWAGELOK FLOW METERING VALVE, 1/4" COMPRESSION, 316SS
12	1	#	(OPTIONAL) THERMAL SHUT OFF VALVE: ‡" or ½" FNPT X FNPT, 300 or 3000 PSI, 125 DEG F SHUT OFF, SS
13	1	#	WARNING LABLES FOR SAMPLE IN AND REMINDER FOR COLD WATER (NOT SHOWN)

Model SCSC201-106-1234: Steam Based Sample Testing



N1. SS SINK, 17" X 15" X 14", W/ 1-1/2" DRAIN

N2. SAMPLÉ COOLER, TYPÉ 2, P/N SC106, 3.8 SF OF HX SURFACE AREA, 3/8" OD, 316 SS COIL

N3. (2) ON/OFF SWAGELOK BALL VALVES, 3/8" COMPRESSION CONNECTIONS

N4. SWAGELOK HIGH FLOW METERING VALVE, 1/4" COMPRESSION, CV .03 @ 300 PSI.

N5. GLOBE VALVE, 3/8" NPT, SS

N6. WALL MOUNT/BRACKET: 20" X 48", X 1/4", W/(2) 1" BENDS ON EACH SIDE, CS, ACRYLIC GREY PAINT FINISH

N7. PRESSURE GAUGE, 0-300 PSI, 1/4" NPT, SS, 2-1/2" DIAL

N8. TEMPERATURE GAUGE, 40-240 DEG F, SS, 1/2" NPT, 3" DIAL

N9. (OPTIONAL) TYGON TUBE ON SAMPLE DISCHARGE

N10. TECHFLEX EXPANDABLE INSULATION SLEEVE

N11. COOLING WATER/SHELL SIDE PRV: SWAGELOK POPPET CHECK VALVE

OTHER NOTES:

A. PIPING: 3/8" OD TUBE, 316 STAINLESS STEEL


B. NAME PLATES SHOWN PROVIDED BY MADDEN

C. PRESSURE RATINGS


COOLING WATER SIDE: 150 PSI DWP

SAMPLE TUBING: 2,500 PSI @ 1,000 DEG F SAMPLE SIDE EQ. AFTER PASS THROUGH: 300 PSI

STEAM SAMPLE, INLET



Model SCSC213-102-106-123456: Free Mount Sample Station Panel



** P&ID's & Notes from Previous two pages apply to this system as well **



SOLD BY:

Fax: (574) 295-7562 Email: info@maddenep.com